

Ademco Vista

Arming	# + 2
Disarming	Code + 1
Bypass	Code + 6 + two digit zone number + #
Stay mode	# + 3
Panic Button	Hold * + # down until sirens sound.
Chime	On press chime Off code + 9
Change codes	Master code + 8 + user number + new code #
Delete code	Code + 8 + user number #